

# Scentra Aromatic Scent Machine Product instruction manual



Thank you sincerely for purchasing the products of our company  
Please keep the instruction manual properly after reading  
for easy reference at any time.

Please read this manual carefully before using the product and keep it safe.

## Precautions

1. After installation, please keep the machine vertical and do not invert, tilt or flip the equipment to avoid oil leakage and damage to the machine.
2. Do not use overloaded sockets. If used, it may endanger your safety and may cause a fire.
3. Please do not try to open the machine shell to avoid damage to the machine. If you are not a technician, you may not modify, disassemble or repair the machine. If the use of the machine is abnormal, please consult sales and after-sales service in time.
4. When the machine is working, do not disassemble the equipment or shake the equipment vigorously, which will cause the machine to work abnormally.
5. Do not place the machine in water or drench it with water.
6. When encountering thunder in natural weather, do not operate the machine to avoid the risk of electric shock.

## Product parameters



|                                     |                                     |
|-------------------------------------|-------------------------------------|
| Machine size: 63*140*160mm          | Voltage: 12V                        |
| Product weight: 0.57kg              | Rated power: 4.6W                   |
| Essential oil capacity: 150ml       | Working noise: ≤35dba               |
| Power supply mode: DC power adapter | Installation: wall-mounted / placed |

## Packaging accessories



Please keep the instruction manual properly after reading

## Operation instructions



1. Insert the key into the keyhole and open the machine cover;
2. Take out the essential oil bottle, open the atomizing head and the essential oil bottle, add essential oil to the essential oil bottle, and install it on the machine.;
3. Connect to the power supply and set the working time of the machine;
4. Close the upper cover and the machine will work according to the set time.

## How to use expansion bolts:



1. Drill a wall hole at the distance of the wall hanging piece, and insert the expansion tube into the wall hole.
2. Install the screws into the expansion tube, and finally hang the equipment.

## How to use seamless wall hanging:

1. Clean the wall, tear off the adhesive of the viscose board and stick it to a flat wall.
2. Hang the machine on the rubber sheet.


## Setup

### boot up:

Connect to the power adapter, insert one end of the power adapter into the machine's dc power access hole [dc power in] plug, and one end into a power socket. At this time, the machine's lcd screen displays the operating status of the system machine.  
[on/off]: the display of on means that the machine is in the running time period, and the display of off means that it is not in the time period.  
[work/pause]: displaying work means that the machine is in a working state, and displaying pause means that the machine is in a paused state.

### Detailed description of key functions:

#### Display screen



The machine settings allow 5 running periods, and the working day of the machine can be selected according to multiple options.

[MODE]: Switch between different page options, including system time, first time period start time, first time period stop time, fragrance concentration. The start time of the second time period, the stop time of the second time period, and the fragrance concentration. The start time of the third time period, the stop time of the third time period, and the fragrance concentration. The start time of the fourth time period, the stop time of the fourth time period, and the fragrance concentration. The start time of the fifth time period, the stop time of the fifth time period, and the fragrance concentration.

[SET]: Enter the setting state, you can skip the setting content of the current page: including time, date, concentration, etc.

[UP]: Fine-tune up, you can adjust the current time period data, fragrance data, and work date selection.

[DOWN]: Fine-tune down, you can adjust the current time period data, fragrance data, and work date selection.

## Equipment running time and adjustment of fragrance concentration

Press the [MODE] button for the first time: [EVENT 1 ON] is displayed on the lcd screen. Press [SET] for the start time of the first period.

The number of hours flashes, adjust the number of hours through [UP/DOWN], or press [SET] for the second time, the number of minutes flashes, and adjust the score through [UP/DOWN], press [SET] the working day number for the time to flash, and adjust the working day through [UP/DOWN].  
(Note: each time period can only select the week in the operating period)

Press the [MODE] button for the second time: the lcd screen displays the end time of the first time period of [EVENT 1 OFF], press the [SET] button to enter the adjustment, and adjust the hours and minutes through [UP/DOWN].

Press the [MODE] button for the third time: [SCENT/WORK] is displayed on the lcd screen to set the working time of the machine for each fragrance spraying cycle. From 5 seconds to 300 seconds, you can adjust it for 5 seconds at a time through [UP/DOWN].

Press the [MODE] button for the fourth time: [SCENE/PAUSE] is displayed on the lcd screen to set the machine pause time for each cycle from 5 seconds to 500 seconds. Press [UP/DOWN] to adjust it for 5 seconds at a time, and continue to press the [MODE] button until all 5 time periods are set.

①(the functions of the 2nd, 3rd, 4th, and 5th time periods are the same as the first time period)  
②(when the running time is set, the shutdown time must not precede the start time. if the running time needs to span 00:00, two time periods need to be set separately)

③if you do not need to set a separate time period, after the first time period is set, press the [MODE] key to directly enter the [SCENT/WORK] mode.

Press and hold the [SET] button for 5 seconds, and the display screen appears [1] to indicate that the button is locked. Press and hold the [SET] button for 5 seconds to unlock the display screen to display the main interface.

Press and hold [DOWN] for 5 seconds, the display [+] appears to indicate that the fan is on, press and hold [DOWN] for 5 seconds, the display [+] disappears to indicate that the fan is off.

## Set the system time

Adjust the setting time and use time to be consistent with the current time. The system time is a 24-hour clock.

Press the [SET] button for the FIRST time: the hour number of the time period flashes, and press [UP/DOWN] to adjust the HOUR.

Press the [SET] BUTTON FOR THE SECOND time: the hour is set, the number of minutes flashes, the score is set, and press [UP/DOWN] to adjust.

Press the [SET] button for the THIRD time: the number of minutes is adjusted, the current working day beats, set the working DAY, and press [UP/DOWN] to adjust.

Press the [SET] button for the fourth time: confirm that the system time is set.


## Restore factory settings

Press and hold the [MODE] button for about 5 seconds to restore to the factory settings.

The factory setting mode is: work every day, working period 08:00-20:00, work for 60 seconds, pause for 60 seconds.

# Mobile APP

## User Manual



Please read the user manual carefully before using this to fully understand how to operate quickly. If you have any questions, please contact our company, and we will strive to provide you with excellent service.

### • Download and install the APP

- ISO users can search for "Scenra Aromatic" in the Apple store scroll down to find the Scenra Aromatic App and install.
- Android users can search for "Scenra Aromatic" in Google Play scroll down to find the Scenra Aromatic App and install.
- All smartphones can scan the QR code and follow the prompts to download and install the program.

Searching for "Scenra Aromatic."



Android




Apple

On the mobile home screen, click "Scenra Aromatic" to enter the app.  
Make sure your Bluetooth is turned on.

From the search list, select the corresponding device and click to connect, then wait for the Bluetooth connection to complete.

- After successful pairing, you will enter the device settings page.

Note: Keep your phone's Bluetooth and location enabled, and stay within a 20 foot unobstructed range of the fragrance device.



### • Device Settings Instructions

Click the "i" button in the upper right corner to open the settings menu.

- Device Info: View the serial number of this device.
- Device Name: Modify the device name for easier identification in different areas, such as living room or game room.
- Fragrance Type: Modify the current diffuser oil name.
- Change Password: Set a 4-digit Bluetooth password.

### • Equipment maintenance

In order to ensure the best aroma effect, customers are requested to inspect and maintain the machine regularly, as follows:

1. Open the lid of the machine and take out the used essential oil bottle;
2. Every time you change the essential oil, you need to clean the essential oil and filter it.;
3. Pour an appropriate amount of alcohol into the essential oil bottle and clean it.;
4. After the sorting is completed, pour a small amount of alcohol, install it on the machine, and turn on the machine to work for 5 to 10 minutes.

(Maintenance once every six months, or when you need to replace a new fragrance, and when you find that the fragrance is getting lighter and lighter)

### • Troubleshooting

| Problem failure              | Solution  |
|------------------------------|---|
| The equipment is not working | <ul style="list-style-type: none"><li>① Check whether the power supply is powered on.</li><li>② Check whether the wrong power supply is used.</li><li>③ Check the working time of the machine settings.</li></ul>   |
| No atomization               | <ul style="list-style-type: none"><li>① Check the color of the machine indicator light.</li><li>② Check whether the air pump is working and whether the atomizing core is clogged.</li><li>③ Check whether the tracheal sealing ring is damaged or falling off.</li><li>④ Check whether the oil suction pipe is clogged or falling off.</li></ul> |
| Small atomization            | <ul style="list-style-type: none"><li>① Check whether the sealing ring of the air outlet pipe is damaged.</li><li>② Check whether the atomizing nozzle is clogged.</li><li>③ Check whether the cooperation between the atomizing core and the atomizing nozzle is loose.</li></ul>  |
| Abnormal noise               | <ul style="list-style-type: none"><li>① Check whether the atomizing head is damaged.</li><li>② Check whether the gasket is damaged and needs to be replaced.</li><li>③ Check whether the essential oil bottle and the atomizing head are tightened in parallel.</li></ul>   |
| Oil leakage                  | <ul style="list-style-type: none"><li>① Check whether the air pump is loose and fix it again.</li><li>② Check whether the air pump is damaged and replace it with a new air pump.</li></ul>   |

### • Work Mode Parameter Settings

Click "work Mode" to set up 5 timers.

- Day Settings: Choose the days of the week for operation.
- Time Settings: Set the device's start and end times.
  - ① The start time must be earlier than the end time.
  - ② If the fragrance program is meant to cover midnight(00:00), two programs must be set: the first up to 23:59 and the second from 00:00.
- Frequency Settings: Adjust the fragrance spray frequency by setting spraytime(seconds) and pause time (seconds).
- After entering the work mode settings, click "Save" to complete the setup.

### • After-sales service

The equipment will be guaranteed within one year from the date of sale, but the shell, wires and other vulnerable objects will not be guaranteed. Damage caused by man-made or accidental is not covered by the warranty.

### • Warning

Risk of Oil Leakage & Damage

- \* Avoid contact with skin, eyes, clothing, or surfaces.
- \* Keep out of reach of children and pets.
- \* Always wear gloves and safety goggles when handling oils or refilling.
- \* Use only as directed and with compatible diffuser machine.
- \* Ensure the diffuser is placed on a stable, protected surface away from heat sources and electrical components.
- \* Place a protective mat or tray under the machine to prevent stains or damage from possible leaks or spills.
- \* Wipe any oil spills immediately to avoid slipping or surface discoloration.
- \* Do not inhale oil directly or use in confined, unventilated spaces.
- \* Disconnect the diffuser from power before refilling or cleaning.
- \* The manufacturer is not responsible for any injury, staining, or property damage caused by leakage, incorrect installation, or misuse.

### • Flammability Notice

Our fragrance oils are carefully crafted for use with scented diffusers. As with all aromatic oils, please keep away from open flames and excessive heat. Store in a cool, dry place, away from direct sunlight. Use only as directed and enjoy your fragrance experience safely.

By Scenra Aromatic.

